L 87405 FL
L 87406 FL

EN User manual

Downloaded from www.vandenborre.be

AEG

perfekt in form und funktion

Downloaded from www.vandenborre.be

CONTENTS

1. SAFETY INFORMATION 3
2. SAFETY INSTRUCTIONS 4
3. PRODUCT DESCRIPTION 6
4. CONTROL PANEL 7
5. PROGRAMMES 11
6. CONSUMPTION VALUES 14
7. BEFORE FIRST USE 14
8. USING THE APPLIANCE 15
9. HINTS AND TIPS 19
10. CARE AND CLEANING 19
11. TROUBLESHOOTING 24
12. TECHNICAL INFORMATION 26

FOR PERFECT RESULTS

Thank you for choosing this AEG product. We have created it to give you impeccable performance for many years, with innovative technologies that help make life simpler – features you might not find on ordinary appliances. Please spend a few minutes reading to get the very best from it.

Visit our website for:

Get usage advice, brochures, trouble shooter, service information:
www.aeg.com

Register your product for better service:
www.aeg.com/productregistration

Buy Accessories, Consumables and Original spare parts for your appliance:
www.aeg.com/shop

CUSTOMER CARE AND SERVICE

We recommend the use of original spare parts.
When contacting Service, ensure that you have the following data available.
The information can be found on the rating plate. Model, PNC, Serial Number.

Warning / Caution-Safety information

General information and tips

Environmental information

Subject to change without notice.

Downloaded from www.vandenborre.be

1. SAFETY INFORMATION

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible if an incorrect installation and use causes injuries and damages. Always keep the instructions with the appliance for future reference.

1.1 Children and vulnerable people safety

⚠ **WARNING!**
Risk of suffocation, injury or permanent disability.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Do not let children play with the appliance.
- Keep all packaging away from children.
- Keep all detergents away from children.
- Keep children and pets away from the appliance door when it is open.
- If the appliance has a child safety device, we recommend you activate it.
- Cleaning and user maintenance shall not be made by children without supervision.

1.2 General Safety

- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Do not change the specification of this appliance.
- Obey the maximum load volume of 10 kg (refer to the “Programme chart” chapter).

Downloaded from www.vanenborre.be

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The operating water pressure (minimum and maximum) must be between 0,5 bar (0,05 MPa) and 8 bar (0,8 MPa)
- The ventilation openings in the base (if applicable) must not be obstructed by a carpet.
- The appliance is to be connected to the water mains using the new supplied hose-sets. Old hose sets must not be reused.

2. ⚠ SAFETY INSTRUCTIONS

2.1 Installation

- Remove all the packaging and the transit bolts.
- Keep the transit bolts. When you move the appliance again you must block the drum.
- Do not install or use a damaged appliance.
- Do not install or use the appliance where the temperature is less than 0 °C or where it is exposed to the weather.
- Obey the installation instruction supplied with the appliance.
- Make sure that the floor where you install the appliance is flat, stable, heat resistant and clean.
- Do not install the appliance where the appliance door can not be fully opened.
- Always be careful when you move the appliance because it is heavy. Always wear safety gloves.
- Make sure that there is air circulation between the appliance and the floor.
- Adjust the feet to have the necessary space between the appliance and the carpet.

Electrical connection

⚠ **WARNING!**
Risk of fire and electrical shock.

- The appliance must be earthed.
- Make sure that the electrical information on the rating plate agrees with the power supply. If not, contact an electrician.
- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Make sure not to cause damage to the mains plug and to the mains cable. Should the appliance power supply cable need to be replaced, this must be carried out by our Service Centre.
- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Do not touch the mains cable or the mains plug with wet hands.
- This appliance complies with the E.E.C. Directives.

Downloaded from www.vandenborre.be

Water connection

- Make sure not to cause damage to the water hoses.
- The appliance is to be connected to the water mains using the new supplied hose-sets. Old hose sets must not be reused.
- Before you connect the appliance to new pipes or pipes not used for a long time, let the water flow until it is clean.
- The first time you use the appliance, make sure that there is no leakage.

2.2 Use

WARNING!
Risk of injury, electrical shock, fire, burns or damage to the appliance.

- Use this appliance in a household environment.
- Do not change the specification of this appliance.
- Obey the safety instructions on the detergent packaging.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.
- Do not touch the glass of the door while a programme operates. The glass can be hot.
- Make sure that you remove all metal objects from the laundry.
- Do not put a container to collect possible water leakage under the appliance. Contact the Service to ensure which accessories can be used.

2.3 Care and Cleaning

WARNING!
Risk of injury or damage to the appliance.

- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Do not use water spray and steam to clean the appliance.
- Clean the appliance with a moist soft cloth. Only use neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.

2.4 Disposal

WARNING!
Risk of injury or suffocation.

- Disconnect the appliance from the mains supply.
- Cut off the mains cable and discard it.
- Remove the door catch to prevent children and pets to get closed in the appliance.

Downloaded from www.vandenborre.be

3. PRODUCT DESCRIPTION





1 Worktop
2 Detergent dispenser
3 Control panel
4 Door handle
5 Rating plate
6 Drain pump
7 Feet for the appliance level
8 Water drain hose
9 Water inlet valve
10 Mains cable
11 Transit bolts
12 Feet for the appliance level

3.1 Child safety device

- When you activate this device, you cannot close the door. This prevents children or pets to be closed in the drum. To activate the device, turn it clockwise, until the groove is horizontal. To deactivate the device, turn it counterclockwise, until the groove is vertical.



3.2 Fixing plate kit (4055171146)

Available from your authorized dealer. If you install the appliance on a plinth, secure the appliance in the fixing plates. Follow the instructions supplied with the kit.

Downloaded from www.vandenborre.be

4. CONTROL PANEL



1 On/Off button (Auto Off)
2 Programme knob
3 Display
4 Start/Pause button (Départ/Pause)
5 Delay Start button (Départ Différé)
6 Time Save button (Gain de Temps)
7 Extra Rinse button (Rinçage Plus)
8 Stains/Prewash button (Taches/Prél-av.)
9 Spin reduction button (Essorage)
10 Temperature button (Temp.)

4.1 AUTO Off button 1

Press this button to activate or deactivate the appliance. A tune sounds when the appliance is activated.

The AUTO OFF function automatically deactivates the appliance to stop the energy consumption when:

- You do not use the appliance for 5 minutes before you press button 4 .
  - All settings are cancelled.
  - Press button 1 to activate the appliance again.
  - Set again the washing programme and all possible options.
- After 5 minutes from the end of the washing programme. Refer to 'At the end of programme'.

4.2 Programme knob 2

Turn this knob to set a programme. The related programme indicator comes on.

Downloaded from www.vandenborre.be

4.3 Display 3



The display shows:

A	88	The temperature of the set programme
	✳	Cold water
B	1888	The spin speed of the set programme
	_ _ _	No Spin symbol[1)]
	▭	Rinse Hold symbol

[1)] Only available for Spin/Drain programme.

C	I	Prewash phase
	II	Washing phase
	≋	Rinses phase
	◎	Spin phase

The phase symbols

- When a programme is set, all the symbols of the phases related to the programme come on.
- When the programme starts, only the symbol of the phase in operation flashes.
- When the programme is completed, the symbol of the last phase is on.

D	☁	The steam symbol comes on when you set a Steam programme.
E		The detergent overdosing comes on at the end of the cycle when the appliance detects too much detergent.

Downloaded from www.vandenborre.be

F		You cannot open the appliance door when the symbol is on. You can open the door only when the symbol goes off. **If the programme is completed but the symbol stays on:** • The 'Rinse Hold' function is on. • There is water in the drum.
G		The delay start symbol comes on when you set the delay start function.
H		• The programme time When the programme starts, the programme time decreases with steps of 1 minute.
		• The delay start When you press the delay start button, the display shows the delay start time.
		• Alarm codes If the appliance has a malfunction, the display shows alarm codes. Refer to 'Troubleshooting'.
		• The display shows this message for some seconds when: – You set a function that is not applicable for the programme. – You change the programme while it operates.
		• When the programme is completed.
I		The child safety lock symbol comes on when this device is activated.

Graphic bars

		The empty indicator bar appears only if the related function is available for the set programme.
		The indicator bar fills accordingly to the set functions.
	If you make a wrong selection the message **Err** indicates that the selection is not possible.	
J		The time save symbol comes on when you set one of the programme duration:
		• Shortened duration
		• Extra Quick
K		The extra rinse symbol comes on when this function is activated.
		The value shows the total number of the rinses.

Downloaded from www.vandenborre.be

		The indicator bar is fully filled when you set to the maximum number of rinses.
L		The Stain symbol comes on when you activate the function.
		The Prewash symbol comes on when you activate the function.
		The indicator bar is not fully filled when you set only one of the functions.
		The indicator bar is fully filled when you set the two functions.

4.4 Start/Pause button 4

Press button 4 to start or interrupt a programme.

4.5 Delay start button 5

Press button 5 to delay the start of a programme from 30 minutes to 20 hours.

4.6 Time save button 6

Press button 6 to decrease the duration of the programme.

– Press one time to set 'Shortened duration' for items with daily soil.
– Press two times to set 'Extra Quick' for items with light soil.

Some programmes accept only one of the two functions.

4.7 Extra rinse button 7

Press button 7 to add rinsing phases to a programme.
Use this function for persons allergic to detergents and in areas where the water is soft.

4.8 Stain-Prewash button 8

Press button 8 to add the stain and/or a prewash phase to a programme.
Press the button again and again to activate one or two options. The related symbol and the indicator bar comes on in the display.

STAIN

- Use this function for laundry with hard stains to remove.

When you set this function, put the stain remover into compartment . This function increases the programme duration.

This function is not available with a temperature lower than 40° C.

PREWASH

- Use this function to add a prewash phase before the washing phase. We recommend that you use this function when you have laundry with a high level of soil.

The set of this function increases the programme duration.

4.9 Spin button 9

Press this button to:

- Decrease the maximum speed of the spin phase of the programme.

The display shows only the spin speeds available with the set programme.

- Deactivate the spin phase.
- Activate the 'Rinse Hold' function. Set this function to prevent fabric creases. The appliance does not drain the water when the programme is completed.

4.10 Temperature button 10

Press button 10 to change the default temperature. When the display shows - -, the appliance does not heat the water.

4.11 Acoustic signals function

You can hear the acoustic signals when:

Downloaded from www.vandenborre.be

- You activate the appliance.
- You deactivate the appliance.
- You press the buttons.
- The programme is completed.
- The appliance has a malfunction.

To **deactivate/activate** the acoustic signals, press button 8 and button 7 at the same time for 6 seconds.

If you deactivate the acoustic signals, they continue operate only when you press the buttons and when a malfunction occurs.

4.12 Child lock function

This function prevents children to play with the control panel.

- To activate the function, press button 10 and button 9 at the same time until the display shows the symbol .
- To deactivate the function, press button 10 and button 9 at the same time until the symbol goes off.

You can activate the function:

- Before you press the Start/Pause button 4 : the appliance cannot start.
- After you press the Start/Pause button 4 , all the buttons and the programme knob are deactivated.

4.13 Permanent extra rinse function

With this function you can keep the extra rinse function permanently on when you set a new programme.

- To **activate** the function press button 6 and button 5 at the same time until the display shows the symbol .
- To **deactivate** the function press button 6 and button 5 at the same time until the symbol goes off.

5. PROGRAMMES

Programme **Temperature range**	**Type of load and soil** **Maximum load, Maximum spin**
Blanc/Couleurs 95°C - Cold	White cotton and coloured cotton. Normal soil and light soil. 10 kg, 1400 rpm
Extra Silence 95°C - Cold	White and coloured cotton. Normal soil and light soil. This cycle eliminates all spinning phases. 10 kg
Synthétiques 60°C - Cold	Synthetic or mixed fabric items. Normal soil and light soil. 4 kg, 1200 rpm
Repassage Facile [1)] 60°C - Cold	Synthetic fabric items. Light soil. 4 kg, 1000 rpm
Délicats 40°C - Cold	Delicate fabrics as acrylics, viscose, polyester items. Normal soil and light soil. 4 kg, 1200 rpm
Laine/Soie 40°C - Cold	Machine washable wool, hand washable wool and delicate fabrics with «hand washing» care symbol. 2 kg, 1200 rpm

Downloaded from www.vandenborre.be

Programme Temperature range	Type of load and soil Maximum load, Maximum spin
Couette 60°C - 30°C	Special programme for one synthetic blanket, duvet, bedspread and so on. 3 kg, 800 rpm
Anti-Allergies 60°C	White cotton items. This programme removes micro-organisms thanks to the washing by 60° C and adds one rinse. In this way the wash is more effective. 10 kg, 1400 rpm
Essorage/Vidange[2)]	To spin the laundry and to drain the water in the drum. All fabrics. 10 kg, 1400 rpm
Rinçage Cold	To rinse and spin the laundry. All fabrics. 10 kg, 1400 rpm
Jeans 60°C - Cold	All items in jeans. Jersey made items with hi-tech materials. 10 kg, 1200 rpm
20 Min. - 3 kg 40°C - 30°C	Cotton and synthetic items with light soil or worn only one time. 3 kg, 1200 rpm
Super Eco[3)] Cold	Mixed fabrics (cotton and synthetic items). 3 kg, 1200 rpm
Coton Eco[4)] 60 °C - 40 °C	White cotton and colour-fast cotton. Normal soil. 10 kg, 1400 rpm
Steam programmes	
Rafraîchir	Steam programme for cotton and synthetic This cycle removes odours from the laundry. 1.5 kg
Défroissage	Steam programme for cotton and synthetic This cycle helps to dewrinkle the laundry. 1.5 kg

1) The wash and spin phase is soft to prevent the creases of the laundry. The appliance adds some rinses.

2) The default phase of the spin speed is related to cotton items. Set the spin speed. Make sure that it agrees with the laundry.

3) Set this programme to decrease the time and the consumption of energy and water.

4) **Standard programmes for the Energy Label consumption values**
According to regulation 1061/2010, these programmes are respectively the «standard 60 °C cotton programme» and the «standard 40 °C cotton programme». They are the most efficient programmes in terms of combined energy and water consumption for washing normally soiled cotton laundry. Set this programme to have a good washing results and decrease the energy consumption. The time of the washing programme is extended.

The water temperature of the washing phase may differ from the temperature declared for the selected programme.

Downloaded from www.vandenborre.be

Programme options compatibility

Programme				Taches/Prélav.	Rinçage Plus	Gain de Temps	Départ Différé
Blanc/Couleurs	■		■	■	■	■	■
Extra Silence				■	■	■	■
Synthétiques	■		■	■	■	■	■
Repassage Facile	■		■	■[1)]	■	■	■
Délicats	■		■	■	■	■	■
Laine/Soie	■		■				■
Couette	■						■
Anti-Allergies	■		■	■	■		■
Essorage/Vidange[2)]	■	■					■
Rinçage	■		■		■		■
Jeans	■		■	■	■		■
20 Min. - 3 kg	■						■
Super Eco	■		■		■		■
Coton Eco	■		■	■	■	■	■

1) Only the prewash function is available.

2) If you set No Spin option the only drain phase is available.

5.1 Woolmark Certificate

The wool wash of this machine has been tested and approved by The Woolmark Company for the washing of wool containing garments labeled as «hand wash» provided that the garments are washed according to the instructions on the garment label and those issued by the manufacturer of this washing machine. M1144
In UK, Eire, Hong Kong and India the Woolmark symbol is a certification trademark.

Downloaded from www.vandenborre.be

6. CONSUMPTION VALUES

At programme start the display shows the duration programme for the maximum load capacity.
During the washing phase the programme duration is automatically calculated and can greatly be reduced if the laundry load is lower than the maximum load capacity (e.g. Cotton 60°C, maximum load capacity 10 kg, the programme duration exceeds 2 hours; real load 1 kg, the programme duration don't reach 1 hour).
When the appliance is calculating the real programme duration a dot blinks in the display.

The data of this table are approximate. Different causes can change the data: the quantity and type of laundry, the water and ambient temperature.

Programmes	Load (Kg)	Energy consumption (kWh)	Water consumption (litre)	Approximate programme duration (minutes)	Remaining moisture (%)[1]
Cottons 60 °C	10	1.80	82	185	52
Cottons 40 °C	10	1.10	82	185	52
Synthetics 40 °C	4	0.60	55	100	35
Delicates 40 °C	4	0.70	62	86	35
Wool/Hand wash 30 °C	2	0.50	59	60	30
Standard cotton programmes					
Standard 60 °C cotton	10	1.13	69	249	52
Standard 60 °C cotton	5	0.76	45	167	52
Standard 40 °C cotton	5	0.52	47	151	52

[1] At the end of spin phase.

Off Mode (W)	Left On Mode (W)
0.05	0.05

The information given in the charts above are in compliance with the EU Commission regulation 1015/2010 implementing directive 2009/125/EC.

7. BEFORE FIRST USE

1. To activate the drain system, put 2 litre of water in the main wash compartment of the detergent dispenser.

Downloaded from www.vandenborre.be

2. Put a small quantity of detergent in the main wash compartment of the detergent dispenser. Set and start a programme for cotton at the highest temperature without laundry. This removes all possible dirt from the drum and the tub.

8. USING THE APPLIANCE

1. Open the water tap.
2. Connect the mains plug to the mains socket.
3. Press button 1 to activate the appliance.
4. Put the laundry in the appliance.
5. Use the correct quantity of detergent and additives.
6. Set and start the correct programme for the type of laundry and soil.

8.1 Loading the laundry

1. Open the appliance door.
2. Put the laundry in the drum, one item at a time. Shake the items before you put them in the appliance. Make sure not to put too much laundry in the drum.
3. Close the door.



Make sure that no laundry stays between the seal and the door. There is a risk of water leakage or damage to the laundry.

8.2 Filling the detergent and additives



I	The detergent compartment for the prewash phase and the soak programme. Add the detergent for prewash and soak before the start of the programme.

Downloaded from www.vandenborre.be

	The detergent compartment for the washing phase. If you use a liquid detergent, put it immediately before you start the programme.
	Liquid additives compartment (fabric conditioner, starch). Put the product in the compartment before you start the programme.
MAX	This is the maximum level for the quantity of liquid additives.
	The compartment for the stain remover. Put the product in the compartment and set the stain function before you start the programme.
	Flap for powder or liquid detergent Turn it (up or down) in the correct position to use powder or liquid detergent.
	Always obey the instructions that you find on the packaging of the detergent products.

Check the position of the flap



1. Pull out the detergent dispenser until it stops.
2. Press the lever down to remove the dispenser.



3. To use powder detergent, turn the flap up.

Downloaded from www.vandenborre.be



4. To use liquid detergent, turn the flap down.

With the flap in the position DOWN:

- Do not use gelatinous or thick liquid detergents.
- Do not put more liquid detergent than the limit showed in the flap.
- Do not set the prewash phase.
- Do not set the delay start function.

5. Measure out the detergent and the fabric conditioner.
6. Carefully close the detergent dispenser. Make sure that the flap does not cause a blockage when you close the drawer.

8.3 Set the delay start

1. Press button 5 again and again until the display shows the number of minutes or hours. The related symbols comes on.
2. Press button 4 , the appliance starts the countdown of the delay start.

   When the countdown is completed, the programme starts automatically.

Before you press button 4 to start the appliance, you can cancel or change the set of the delay start.
You cannot set the delay start with the **Steam** programme.

8.4 Cancel the delay start

1. Press button 4 . The related indicator flashes.
2. Press button 5 again and again until the display shows **0'**.
3. Press button 4 . The programme starts.

8.5 Setting and starting a programme

1. Turn the programme knob. The related programme indicator comes on.
2. The indicator of button 4 flashes with red colour.
3. The display shows the default temperature, the spin speed and the empty indicator bars of the available functions.
4. To change the temperature and/or the spin speed, press the related buttons.
5. Set the available functions.
6. Press button 4 to start the programme. The indicator of button 4 is on.

The drain pump can operate for a short time when the appliance fills water.

The appliance adjust automatically the cycle time to the laundry you have put in the drum to have perfect washing results in the minimum necessary time. After approximately 15 minutes from the start of the programme, the display shows the new time value.

8.6 Interrupt a programme

1. Press button 4 . The indicator flashes.

Downloaded from www.vantenborre.be

2. Press button 4 again. The washing programme continues.

8.7 Cancel a programme

1. Press button 1 to cancel the programme and to deactivate the appliance.
2. Press button 1 again to activate the appliance. Now, you can set a new washing programme.

The appliance does not drain the water.

8.8 Change a function

You can change only some functions before they operate.

1. Press button 4 . The indicator flashes.
2. Change the function set.

8.9 Open the door

While a programme or the delay start operates, the appliance door is locked.

To open the appliance door:

1. Press button 4 . The door lock symbol in the display goes off.
2. Open the appliance door.
3. Close the appliance door and press button 4 . The programme or the delay start continues.

If the temperature and level of the water in the drum are too high, the door lock symbol stays on and you cannot open the door. To open the door do the steps that follow:

1. Deactivate the appliance.
2. Wait for some minutes.
3. Make sure that no water is in the drum.

If you deactivate the appliance, it is necessary to set the programme again.

8.10 At the end of the programme

- The appliance stops automatically.
- The acoustic signals operate.
- In the display 0 comes on.
- The indicator of the Start/Pause button 4 goes off.
- The door lock symbol goes off.
- Press button 1 to deactivate the appliance. After five minutes from the end of the programme, the energy saving function automatically deactivates the appliance.

When you activate the appliance again, the display show the end of the last set programme. Turn the programme knob to set a new cycle.

- Remove the laundry from the appliance. Make sure that the drum is empty.
- Keep the door ajar, to prevent mildew and odours.
- Close the water tap.

The washing programme is completed, but there is water in the drum:

– The drum turns regularly to prevent the creases in the laundry.
– The door stays locked.
– You must drain the water to open the door.

To drain the water:

1. If necessary, decrease the spin speed.
2. Press the Start/Pause button 4 . The appliance drain the water and spin.
3. When the programme is completed and the door lock symbol goes off, you can open the door
4. Deactivate the appliance.

The appliance drain and spin automatically after approximately 18 hours.

Downloaded from www.vandenborre.be

9. HINTS AND TIPS

9.1 The laundry load

- Divide the laundry in: white, coloured, synthetics, delicates and wool.
- Obey the washing instructions that are on the laundry care labels.
- Do not wash together white and coloured items.
- Some coloured items can discolour with the first wash. We recommend that you wash them separately for the first times.
- Button up pillowcases, close zippers, hooks and poppers. Tie up belts.
- Empty the pockets and unfold the items.
- Turn inside out multilayered fabrics, wool and items with painted illustrations.
- Remove hard stains.
- Wash with a special detergent heavy soil stains.
- Be careful with the curtains. Remove the hooks or put the curtains in a washing bag or pillowcase.
- Do not wash in the appliance :
  - Laundry without hems or with cuts
  - Underwired bras.
  - Use a washing bag to wash small items.
- A very small load can cause balance problems with the spin phase. If this occurs, adjust manually the items in the tub and start the spin phase again.

9.2 Stubborn stains

For some stains, water and detergent is not sufficient.
We recommend that you remove these stains before you put the items in the appliance.

Special stain removers are available. Use the special stain remover that is applicable to the type of stain and fabric.

9.3 Detergents and additives

- Only use detergents and additives specially made for washing machines.
- Do not mix different types of detergents.
- To help the environment, do not use more than the correct quantity of detergent.
- Obey the instructions that you find on the on packaging of these products.
- Use the correct products for the type and colour of the fabric, the programme temperature and the level of soil.
- If you use liquid detergents, do not set the prewash phase.
- If your appliance has not the detergent dispenser with the flap device, add the liquid detergents with a dosing ball.

9.4 Water hardness

If the water hardness in your area is high or moderate, we recommend that you use a water softener for washing machines. In areas where the water hardness is soft it is not necessary to use a water softener.
To know the water hardness in your area, contact your local water authority.
Obey the instructions that you find on the packaging of the products.

10. CARE AND CLEANING

WARNING!

Disconnect the appliance from the mains supply before you clean it.

Downloaded from www.vandenborre.be

10.1 Descaling

The water we use contains limescale. If it becomes necessary, use a water softener to remove limescales.
Use a special product made for washing machines. Obey the instructions that you find on the packaging of the manufacturer.
Do this separately from the laundry wash.

10.2 External cleaning

Clean the appliance only with soap and warm water. Fully dry all the surfaces.

CAUTION!
Do not use alcohol, solvents or chemical products.

10.3 Maintenance wash

With the low temperature programmes it is possible that some detergent stays in the drum. Make regularly a maintenance wash. To do this:

- Empty the laundry from the drum.
- Set the hottest cotton wash programme
- Use a correct quantity of powder detergent with biological properties.

After each wash, keep the door open for a while to prevent mould and to let unpleasant smells go out.

10.4 Door seal



Regularly examine the seal and remove all objects from the inner part.

10.5 Drum

Regularly examine the drum to prevent limescale and rust particles.
Only use special products to remove rust particles from the drum.
To do this:

- Clean the drum with special product for stainless steel.
- Start a short programme for cotton at the maximum temperature with a small quantity of detergent.

10.6 Detergent dispenser

To clean the dispenser:



1. Press the lever.
2. Pull the dispenser out.

Downloaded from www.vandenborre.be



3. Remove the top part of the liquid additive compartment.
4. Clean all the parts with water.



5. Clean the dispenser recess with a brush.
6. Put back the dispenser in the recess.

10.7 Drain pump

Regularly examine the drain pump and make sure that it is clean.

Clean the pump if:

- The appliance does not drain the water.
- The drum cannot turn.
- The appliance makes an unusual noise because of the blockage of the drain pump.
- The display shows an alarm code because of the problem with water drain.

WARNING!

1. Disconnect the mains plug from the mains socket.
2. Do not remove the filter while the appliance operates. Do not clean the drain pump if the water in the appliance is hot. The water must be cold before you clean the drain pump.

To clean the drain pump:



1. Open the drain pump door.



2. Pull the flap out to remove it.

Downloaded from www.vandenborre.be



3. Put a container below the recess of the drain pump to collect the water that flows out.
4. Press the two levers and pull forward the drainage duct to let the water flow out.



5. When the container is full of water, put the drainage duct back again and empty the container. Do steps 4 and 5 again and again until no more water flows out from the drain pump.
6. Pull back the drainage duct and turn the filter to remove it.



7. Remove fluff and objects from the pump.



8. Make sure that the impeller of the pump can turn. If this does not occur, contact the service centre.



9. Clean the filter under the water tap and put it back in the pump into the special guides.
10. Make sure that you tighten correctly the filter to prevent leakages.
11. Put the flap back and close the drain pump door.

10.8 The inlet hose filter and the valve filter

It could be necessary to clean the filters when:

- The appliance does not fill with water.
- The appliance fills with the water for a long time.
- The indicator of button 4 flashes and the display shows the related alarm. Refer to 'Troubleshooting'.

WARNING!
Disconnect the mains plug from the mains socket.

Downloaded from www.vandenborre.be

To clean the water inlet filters:



1. Close the water tap.
2. Remove the water inlet hose from the water tap.
3. Clean the filter in the inlet hose with a stiff brush.



4. Remove the inlet hose behind the appliance.
5. Clean the filter in the valve with a stiff brush or a towel.



6. Install again the inlet hose. Make sure that the couplings are tight to prevent leakages.
7. Open the water tap.

10.9 Emergency drain

Because of a malfunction, the appliance cannot drain the water.
If this occurs, do steps (1) through (6) of 'To clean the drain pump'.
If necessary, clean the pump.
Put the drainage duct back and close the drain pump flap.
When you drain the water with the emergency drain procedure, you must activate again the drain system:

1. Put 2 litres of water in the main wash compartment of the detergent dispenser.
2. Start the programme to drain the water.

10.10 Frost precautions

If the appliance is installed in an area where the temperature can be less than 0 °C, remove the remaining water from the inlet hose and the drain pump.

1. Disconnect the mains plug from the mains socket.
2. Close the water tap.
3. Remove the water inlet hose
4. Put the two ends of the inlet hose in a container and let the water flow out of the hose.
5. Empty the drain pump. Refer to the emergency drain procedure
6. When the drain pump is empty, install the inlet hose again.

WARNING!
Make sure that the temperature is more than 0 °C before you use the appliance again.
The manufacturer is not responsible for damages caused by low temperatures.

Downloaded from www.vandenborre.be

11. TROUBLESHOOTING

The start of the appliance does not occur or it stops during operation.
First try to find a solution to the problem (refer to the table). If not, contact the service centre.

With some problems, the acoustic signals operate and the display shows an alarm code:

- E10 - The appliance does not fill with water properly.
- E20 - The appliance does not drain the water.
- E40 - The appliance door is open or not closed correctly.
- EF0 - The anti-flood device is on.

WARNING!
Deactivate the appliance before you do the checks.

Problem	Possible cause	Possible solution
The appliance does not fill with water properly.	The water tap is closed.	Open the water tap.
	The water inlet hose is damaged.	Make sure that the water inlet hose has no damages.
	The filters in the water inlet hose is blocked .	Clean the filters. Refer to 'Care and cleaning'.
	The water tap is blocked or is furred with limescale.	Clean the water tap.
	The connection of the water inlet hose is not correct.	Make sure that the connection is correct.
	The water pressure is too low.	Contact your local water authority.
	The end of the drain hose is too low.	Make sure that the drain hose is in the correct position.
The appliance does not drain the water.	The water drain hose is damaged.	Make sure that the water drain hose has no damages.
	The filter of the drain pump is blocked.	Clean the filter of the drain pump. Refer to 'Care and cleaning'.
	The connection of the water drain hose is not correct.	Make sure that the connection is correct.
	A washing programme without the drain phase is set.	Set the drain programme.
	The function Rinse & Hold is on.	Set the drain programme.

Downloaded from www.vandenborre.be

Problem	Possible cause	Possible solution
The appliance door is open or not closed correctly.		Close the door correctly.
The anti-flood device is on.		• Disconnect the appliance. • Close the water tap. • Contact the service centre.
The spin phase does not operate.	The spin phase is off.	Set the spin programme.
	The filter of the drain pump is blocked.	Clean the filter of the drain pump. Refer to 'Care and cleaning'.
	Balance problems with the laundry load.	Adjust manually the items in the tub and start the spin phase again.
The programme does not start.	The mains plug is not connected in the mains socket.	Put in the mains plug.
	Blow out fuse in the household fuse box.	Replace the fuse.
	You did not press button 4 .	Press button 4 .
	The delay start is set.	To start immediately the programme, cancel the delay start.
	The Child Lock function is activated.	Deactivate the Child Lock function.
There is water on the floor.	Leakages from the couplings of the water hoses.	Make sure that the couplings are tight.
	Leakages from the drain pump.	Make sure that the drain pump filter is tight.
	The water drain hose is damaged.	Make sure that the water inlet hose has no damages.
You cannot open the appliance door.	The washing programme is in operation.	Let the washing programme end.
	There is water in the drum.	Set the drain or the spin programme.
The appliance makes an unusual noise.	Incorrect level of the appliance.	Adjust the level of the appliance. Refer to 'Installation'.
	You did not remove the packaging and/or the transit bolts.	Remove the packaging and/or the transit bolts. Refer to 'Installation'.

Downloaded from www.vandenborre.be

Problem	Possible cause	Possible solution
	The load is very small.	Add more laundry in the drum.
The cycle is shorter than the time displayed.	The appliance calculates a new time according to the laundry load.	See the 'Consumption Values' chapter.
The cycle is longer than the time displayed.	An unbalanced laundry load increases the duration time.	This is a normal behaviour of the appliance.
The washing results are not satisfactory.	The detergent you used was not sufficient or correct.	Increase the detergent quantity or use a different one.
	You did not remove the stubborn stains before you wash the laundry.	Use special products to remove the stubborn stains.
	Incorrect temperature was set.	Make sure that you set the correct temperature.
	Too much laundry load.	Decrease the laundry load.

After the check, activate the appliance. The programme continues from the point of interruption.
If the problem occurs again, contact the service centre.

If the display shows other alarm codes, contact the service centre.

12. TECHNICAL INFORMATION

Dimensions	Width / Height / Depth	600 / 850 / 605 mm
	Total depth	640 mm
Electrical connection:	Voltage Overall power Fuse Frequency	230 V 2200 W 10 A 50 Hz
Level of protection against ingress of solid particles and moisture ensured by the protective cover, except where the low voltage equipment has no protection against moisture		**IPX4**
Water supply pressure	Minimum	0,5 bar (0,05 MPa)
	Maximum	8 bar (0,8 MPa)
Water supply [1]		Cold water
Maximum load	Cotton	10 kg
Spin speed	Maximum	1400 rpm

[1] Connect the water inlet hose to a water tap with a 3/4'' thread.

13. ENVIRONMENT CONCERNS

Recycle the materials with the symbol ♺ . Put the packaging in applicable containers to recycle it. Help protect the environment and human health and to recycle waste of electrical and electronic appliances. Do not dispose appliances marked with the symbol with the household waste. Return the product to your local recycling facility or contact your municipal office.

Downloaded from www.vandenborre.be

www.aeg.com/shop

Downloaded from www.vandenborre.be

132910440-A-382013

CE

AEG

perfekt in form und funktion